

Ro Óg BalanceBoard - Maintenance:

- Timber Balance Boards are more suitable to long term use than other materials.
- Ro Óg Balance Boards are designed to be used by children and adults.
- Clean with a damp cloth do not use abrasives or bleach.
- Do not immerse the product in water and do not leave in damp areas as this will cause damage.
- Do not modify the balance board as this could reduce safety.
- Do not use the balance board if any parts are cracked or missing.
- Do not use replacement parts other than those approved by the manufacturer.
- A specialised waterproof wax finish has been used on the board, details of the finish can be obtained by contacting the manufacturer
- The correct use and maintenance of the product will ensure it gives long and trouble free use.



Address:

Liá Fáil, Carhue North,
Riverstick, Co.Cork.
Ireland.

Web:

www.roogltd.com

Tel:

021 477 1983

Mob:

086 8345 867

Email:

roogltd@gmail.com